


170.206.23 KA 170.206.23 KP 170.206.23 KM 170.206.23 KR 170.206.23 K1



TUTTE LE VARIANTI
ALL MODELS

170.1005.15




SOLO VARIANTE K1
ASSEMBLARE CON LOXEAL 56-03
SU 170.215.1
K1 MODEL ONLY
ASSEMBLE WITH LOXEAL 56-03
ON 170.215.1

SOLO VARIANTI KM E KP
KM AND KP MODELS ONLY




180.1305.27

SOLO VARIANTI KP E KR
KP AND KR MODELS ONLY



709.1504.59

TUTTE LE VARIANTI
ALL MODELS




SOLO VARIANTE K1
ASSEMBLARE SU 170.208.151
K1 MODEL ONLY
ASSEMBLE ON 170.208.151

TUTTE LE VARIANTI
ALL MODELS





170.2017

SOLO VARIANTE K1
ASSEMBLARE CON LOXEAL 56-03
ORIENTARE VERSO SCARICO
K1 MODEL ONLY
ASSEMBLE WITH LOXEAL 56-03
TOWARDS THE BACKFLOW



170.1012.5
MANUALE M170 OT



COME SI ORDINA/HOW TO ORDER
Kit ricambio
Spare parts kit **172.302.61.**

COME SI ORDINA/HOW TO ORDER
Kit ricambio
Spare parts kit **170.302.30**