



**M90**



**M75**



**M65**



**SPRAY ADJUST  
KIT**



**M92**



**M82**



**M62**

## SPRAY NOZZLES M90, M75, M65, M92, M82, M62, SPRAY ADJUST KIT

This newsletter compares six of our **fix and adjustable brass nozzles** showing all of their features.

**Braglia<sup>®</sup> check valve** is a common feature to all nozzles: thanks to our factory set we assure efficient and **long lasting operations at low and high pressures**.

Every model is designed to be as **compact** as possible but still having wide inner spaces to keep **pressure drop at its minimum**.

Next page shows a **comparative table** of our nozzle

For information or offer please contact:

✉ [claudiacalzoni@braglia.it](mailto:claudiacalzoni@braglia.it) - sales department

✉ [giorgiozecchini@braglia.it](mailto:giorgiozecchini@braglia.it) - area manager

🌐 [www.braglia.it/M90](http://www.braglia.it/M90) - [www.braglia.it/M92](http://www.braglia.it/M92)

[www.braglia.it/M75](http://www.braglia.it/M75) - [www.braglia.it/M82](http://www.braglia.it/M82)

[www.braglia.it/M65](http://www.braglia.it/M65) - [www.braglia.it/M62](http://www.braglia.it/M62)



	M90	M75	M65	SPRAY ADJ. KIT	M92	M82	M62
Max. operating pressure	40 bar / 600 psi	40 bar / 600 psi	40 bar / 600 psi	40 bar / 600 psi	40 bar / 600 psi	40 bar / 600 psi	40 bar / 600 psi
Plus	Top line. FKM seals, no pressure drops	Standard	Entry level	For M65, M70, M75, M76, M84, M90	Top line. FKM seals, no pressure drops. Adjustable spray angle side for Ø15 and Ø18 tips	Standard. Adjustable spray angle side for Ø15 tips	Entry level. Adjustable spray angle side for Ø15 and Ø18 tips
Standard	Standard with caps, spray tips not included. BRAGLIA® check valve	Standard with caps, spray tips not included. BRAGLIA® check valve	Standard with caps, spray tips not included. BRAGLIA® check valve	Standard with seal. Caps and Ø15/Ø18 M92 kit not included	Standard with caps, spray tips not included. BRAGLIA® check valve	<ul style="list-style-type: none"> <li>Adjustable side: Ch20 nut G3/8 BSPF and AMT Ø15 spray tip</li> <li>Fixed side: M75 Ø15 nut or AD / AC nut kit.</li> </ul> BRAGLIA® check valve	Standard with caps, spray tips not included. BRAGLIA® check valve
Model	<ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul>	<ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul>	<ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul>	<ul style="list-style-type: none"> <li>For ALBUZ® Ø15 and Ø18 Kit</li> </ul>	<ul style="list-style-type: none"> <li>Ø15 and Ø18 nozzle holder</li> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with G3/8 BSPF. nut</li> <li>82.617.68 G1/4 BSPM: FKM seals</li> <li>82.617.18 SU: G1/4 BSPM: adjustable spray angle side without spray tip</li> </ul>	<ul style="list-style-type: none"> <li>Ø15 and Ø18 nozzle holder</li> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul>	
For ALBUZ® tips	<ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI,</li> <li>ALBUZ® AD/AC</li> </ul>	<ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI,</li> <li>ALBUZ® AD/AC</li> </ul>	<ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI,</li> <li>ALBUZ® AD/AC</li> </ul>	<ul style="list-style-type: none"> <li>ALBUZ® Ø15, Ø18 kit</li> </ul>	<ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15, AMT Ø18</li> <li>Fixed side: ALBUZ® Ø15 and Ø18 kit, ATR, TVI, AD/AC</li> </ul>	<ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15</li> <li>Fixed side: ALBUZ® Ø15 kit, ATR, TVI, AD/AC</li> </ul>	<ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15, AMT Ø18</li> <li>Fixed side: ALBUZ® Ø15 and Ø18 kit, ATR, TVI, AD/AC</li> </ul>