







POSIZIONE DI PARTENZA 180.620.6
180.620.6 STARTING POSITION






RIFERIMENTO / NOTCH
180.1304.55



POSIZIONE DI ASSEMBLAGGIO 180.1604.17
E 180.1304.55 NEL 180.107.80 - SCALA 1:1

180.1604.17 AND 180.1304.55 ASSEMBLING
POSITION INSIDE 180.107.80 - SCALE 1:1




POSIZIONE DI PARTENZA 180.1604.17 E 180.1304.55
PER MONTAGGIO 180.620.6 - SCALA 1:1

180.1604.17 AND 180.1304.55 STARTING POSITION
FOR 180.620.6 ASSEMBLING - SCALE 1:1

Per innestare 180.620.6 ruotare 180.1304.55
5°/10° dalla posizione di partenza nel verso
indicato dalla freccia

To engage 180.620.6 rotate 180.1304.55 from
starting position 5°/10° in the arrow direction

SOLO PER KIT
FOR KIT ONLY



COME SI ORDINA / HOW TO ORDER
Kit ricambio
Spare parts kit

180.302.32.