


**M90**



**M75**



**M65**



**SPRAY ADJUST  
KIT**



**M92**



**M82**



**M62**

## SPRAY NOZZLES M90, M75, M65, M92, M82, M62, SPRAY ADJUST KIT

This newsletter compares six of our **fix and adjustable brass nozzles** showing all of their features.

**Braglia® check valve** is a common feature to all nozzles: thanks to our factory set we assure efficient and **long lasting operations at low and high pressures.**

Every model is designed to be as **compact** as possible but still having wide inner spaces to keep **pressure drop at its minimum.**

Next page shows a **comparative table** of our nozzle

For information or offer please contact:

✉ [claudiacalzoni@braglia.it](mailto:claudiacalzoni@braglia.it) - sales department

✉ [stefanobraglia@braglia.it](mailto:stefanobraglia@braglia.it) - sales manager

🌐 [www.braglia.it/M90](http://www.braglia.it/M90) - [www.braglia.it/M92](http://www.braglia.it/M92)

[www.braglia.it/M75](http://www.braglia.it/M75) - [www.braglia.it/M82](http://www.braglia.it/M82)

[www.braglia.it/M65](http://www.braglia.it/M65) - [www.braglia.it/M62](http://www.braglia.it/M62)



|                                | M90  | M75  | M65  | SPRAY ADJ. KIT   | M92  | M82  | M62   |
|--------------------------------|--|--|--|--|--|--|---|
| <b>Max. operating pressure</b> | 40 bar / 600 psi   | 40 bar / 600 psi   | 40 bar / 600 psi   | 40 bar / 600 psi   | 40 bar / 600 psi   | 40 bar / 600 psi   | 40 bar / 600 psi  |
| <b>Plus</b>                    | Top line. FKM seals, no pressure drops   | Standard   | Entry level  | For M65, M70, M75, M76, M84, M90   | Top line. FKM seals, no pressure drops. Adjustable spray angle side for Ø15 and Ø18 tips   | Standard. Adjustable spray angle side for Ø15 tips   | Entry level. Adjustable spray angle side for Ø15 and Ø18 tips   |
| <b>Standard</b>                | Standard with caps, spray tips not included.<br>BRAGLIA® check valve   | Standard with caps, spray tips not included.<br>BRAGLIA® check valve   | Standard with caps, spray tips not included.<br>BRAGLIA® check valve   | Standard with seal. Caps and Ø15/Ø18 M92 kit not included                    | Standard with caps, spray tips not included.<br>BRAGLIA® check valve   | <ul style="list-style-type: none"> <li>Adjustable side: Ch20 nut G3/8 BSPF and AMT Ø15 spray tip</li> <li>Fixed side: M75 Ø15 nut or AD / AC nut kit.</li> </ul> BRAGLIA® check valve  | Standard with caps, spray tips not included.<br>BRAGLIA® check valve  |
| <b>Model</b>                   | <ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul> | <ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul> | <ul style="list-style-type: none"> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul> | <ul style="list-style-type: none"> <li>For ALBUZ® Ø15 and Ø18 Kit</li> </ul> | <ul style="list-style-type: none"> <li>Ø15 and Ø18 nozzle holder</li> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with G3/8 BSPF. nut</li> <li>82.617.68 G1/4 BSPM: FKM seals</li> <li>82.617.18 SU: G1/4 BSPM: adjustable spray angle side without spray tip</li> </ul> | <ul style="list-style-type: none"> <li>Ø15 nozzle holder</li> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with G3/8 BSPF. nut</li> <li>82.617.68 G1/4 BSPM: FKM seals</li> <li>82.617.18 SU: G1/4 BSPM: adjustable spray angle side without spray tip</li> </ul> | <ul style="list-style-type: none"> <li>Ø15 and Ø18 nozzle holder</li> <li>G1/4 BSPM with nut and O-Ring</li> <li>G1/4 BSPF</li> <li>G3/8 BSPM - 1/8 BSPF: with nut</li> </ul> |
| <b>For ALBUZ® tips</b>         | <ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI, AD/AC</li> </ul>                                   | <ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI, AD/AC</li> </ul>                                   | <ul style="list-style-type: none"> <li>ALBUZ® Ø15 and Ø18 kit</li> <li>ALBUZ® ATR, TVI, AD/AC</li> </ul>                                   | <ul style="list-style-type: none"> <li>ALBUZ® Ø15, Ø18 kit</li> </ul>        | <ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15, AMT Ø18</li> <li>Fixed side: ALBUZ® Ø15 and Ø18 kit, ATR, TVI, AD/AC</li> </ul>   | <ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15</li> <li>Fixed side: ALBUZ® Ø15 kit, ATR, TVI, AD/AC</li> </ul>  | <ul style="list-style-type: none"> <li>Adjustable side: AMT Ø15, AMT Ø18</li> <li>Fixed side: ALBUZ® Ø15 and Ø18 kit, ATR, TVI, AD/AC</li> </ul>                              |