







POSIZIONE DI PARTENZA 180.620.6  
180.620.6 STARTING POSITION




RIFERIMENTO / NOTCH  
180.1304.55




POSIZIONE DI ASSEMBLAGGIO 180.1604.17  
E 180.1304.55 NEL 180.107.80 - SCALA 1:1

180.1604.17 AND 180.1304.55 ASSEMBLING  
POSITION INSIDE 180.107.80 - SCALE 1:1



RIFERIMENTO / NOTCH  
180.1304.55



POSIZIONE DI PARTENZA 180.1604.17 E 180.1304.55  
PER MONTAGGIO 180.620.6 - SCALA 1:1

180.1604.17 AND 180.1304.55 STARTING POSITION  
FOR 180.620.6 ASSEMBLING - SCALE 1:1

Per innestare 180.620.6 ruotare 180.1304.55  
5°/10° dalla posizione di partenza nel verso  
indicato dalla freccia

To engage 180.620.6 rotate 180.1304.55 from  
starting position 5°/10° in the arrow direction

SOLO PER KIT  
FOR KIT ONLY

- 71.602.6
- 180.306.1 x 2
- 180.601.2
- 142.602.18
- 180.602.48
- 180.801.43
- 180.1009.1 x 2
- 180.1603.18
- 180.1603.23

COME SI ORDINA / HOW TO ORDER  
Kit ricambio  
Spare parts kit **180.302.32.**